

AWAINTI™

Competition Pellet Rifles

OPERATION MANUAL



888
MEDALIST



887 GOLD
MEDALIST

⚠ WARNING: NOT A TOY. THIS AIRGUN IS DESIGNED FOR USE BY EXPERIENCED SHOOTERS AND IS INTENDED FOR MATCH COMPETITION OR TARGET RANGE USE. MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY OR DEATH. MAY BE DANGEROUS UP TO 257 YARDS (235 METERS).

THIS IS A SPECIAL CLASS OF NON-POWDERED GUNS AND NOT FOR GENERAL USE. IT IS TO BE USED FOR TRAINING AND TARGET SHOOTING UNDER SUPERVISION. RECOMMENDED FOR USE BY THOSE 16 YEARS OF AGE OR OLDER. THIS GUN SHOOTS PELLETS ONLY. READ ALL INSTRUCTIONS BEFORE USING. THE PURCHASER AND USER SHOULD CONFORM TO ALL LAWS GOVERNING THE USE AND OWNERSHIP OF AIRGUNS.

Use .177 cal. (4.5 mm) Lead Airgun Pellets 



WARNING: THIS GUN CAN CAUSE SERIOUS INJURY OR DEATH. READ AND FOLLOW THE INSTRUCTIONS CAREFULLY. DO NOT LOAD A PELLET INTO THE GUN UNTIL YOU ARE READY TO SHOOT. IF YOU DO LOAD A PELLET AND THEN DECIDE NOT TO SHOOT, REMOVE IT EITHER MANUALLY OR BY SHOOTING THE GUN AT A SAFE TARGET. AN UNLOADED, UNCOCKED GUN WHICH IS “ON” SAFETY IS SAFEST. ACCIDENTS HAPPEN FAST, AND ACCIDENTALLY INJURING OR KILLING SOMEONE IS A TERRIBLE THING. PLEASE SHOOT SAFELY.



This safety alert symbol indicates important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

The Avanti Models 887 and 888 Competition Pellet Rifles shoot with much more muzzle energy than many BB and pellet guns. Use extreme caution when operating these guns. Although your new Avanti Competition Air Rifle is not a firearm, it has lethal potential and should be treated with the caution and respect due any conventional firearm. Like a firearm, your Avanti Competition Air Rifle, when misused or carelessly used, can kill or seriously injure the shooter or other persons. Always remember, the first and most important safety feature of any gun is the shooter. All safeties are mechanical devices and the shooter is the only part of the system that can make a gun safe or unsafe. **DON'T DEPEND ON MECHANICAL SAFETIES** – think ahead and avoid situations that might lead to accidents.

Guns differ in their operation, and you are never ready to fire any gun until you are thoroughly familiar with it. Read the following operating instructions and, **WITHOUT LOADING ANY PELLETS**, proceed through the operating steps, dry firing your gun several times at a safe target. This will enable you to learn to operate this Avanti Competition Air Rifle properly and safely.

NOTE: Models 887 and 888 are identical except for stock and sights.

MODEL 887 SHOWN






FIGURE NO. 1

HOW TO OPERATE

⚠ WARNING: BE SURE GUN IS ALWAYS POINTED IN A SAFE DIRECTION.

- Step 1. PUT “ON” TRIGGER SAFETY (NO RED SHOWING)
- Step 2. OPEN BOLT
- Step 3. INSTALL CO2
- Step 4. LOAD PELLET
- Step 5. CLOSE BOLT

- Step 6. AIM AT SAFE TARGET
- Step 7. TAKE “OFF” TRIGGER SAFETY (RED SHOWING)
- Step 8. FIRE



⚠ WARNING: BE SURE GUN IS ALWAYS POINTED IN A SAFE DIRECTION. NEVER POINT THE GUN AT ANYONE. ALWAYS ASSUME AND HANDLE THE GUN AS IF IT WERE LOADED AND READY TO FIRE.

STEP 1. PUT “ON” TRIGGER SAFETY

Push the trigger safety from left to right so that NO RED IS SHOWING. It is a good practice to get into the habit of always keeping the trigger safety “ON” (NO RED SHOWING) until actually ready to fire the gun. (See Drawing 1A)

STEP 2. OPEN BOLT

Pull the bolt handle fully to the rear. Then, release your hold on the bolt handle, leaving the bolt open. The gun cannot fire with the bolt open. (See Drawing 1B)


STEP 3. INSTALL CO2

The model 887 and 888 CO2 pellet rifles are energized by CO2 only, from a refillable 2.5 ounce removable CO2 bottle (cylinder) designed for use in this model.

⚠ WARNING: DO NOT ATTEMPT TO USE COMPRESSED AIR, OR ANY GASSES OTHER THAN CO2 IN THESE MODELS.

⚠ WARNING: DO NOT ATTEMPT TO USE ANY TYPE OF CO2 BOTTLE, CYLINDER, OR FITTINGS THAT THIS MODEL IS NOT DESIGNED TO USE.

A newly purchased Daisy 2.5 ounce refillable CO2 bottle (cylinder) will be empty. It will not have CO2 in it until it has been filled. These bottles can be filled with CO2 at stores where CO2 paintball marker cylinders are filled.



INSTALLING THE FILLED 2.5 OUNCE REFILLABLE CO2 BOTTLE (CYLINDER) INTO THE GUN:

⚠ WARNING: USE ONLY WRENCH PROVIDED. OVER-TIGHTENING CYLINDER MAY CAUSE SERIOUS INJURY.

Over-tightening a CO2 cylinder during installation can cause severe damage to the cylinder threads which may result in serious injury to the person installing the cylinder.

The most common cause of over-tightening is using a wrench other than the one included with the cylinder. Other wrenches provide more torque than the wrench provided and can severely damage the cylinder. Because the O-ring on the cylinder – not a brass-to-brass seal – is the true point of seal, over-tightening does NOT ensure a better seal. Rather, it can destroy the O-ring, damage the threads of the cylinder and the rifle, prevent a correct and effective seal and cause damage leading to serious injury.

INSTALLING: Coat the threads of the bottle and the O-ring with 30-weight non-detergent motor oil. Keep the gun pointed in a safe direction. IT IS VERY IMPORTANT TO ALWAYS KEEP THE GUN POINTED IN A SAFE DIRECTION WHILE INSTALLING OR REMOVING THE CO2 BOTTLE (CYLINDER).

Insert the threaded fitting end of the CO2 bottle (cylinder) into the forearm of gun. (See Drawing 2A)


Using only wrench provided, screw the bottle (cylinder) inward until it is seated. (See Drawing 2B). DO NOT OVER TIGHTEN. Use only the wrench provided with the gun, to prevent the bottle from being over tightened. Using any other wrench will produce more torque than the wrench provided, damaging threads and resulting in serious injury.

With the gun pointed in a safe direction, it can then be dry fired, with CO2 only, to find out if the CO2 bottle (cylinder) is installed correctly. If no CO2 shoots from the gun, the shooter should retighten the CO2 bottle (cylinder) again using only the wrench provided, being careful not to over tighten it. Never assume any gun is unloaded. Follow all safety rules.

O-RINGS: The O-ring on the refillable CO2 bottle (cylinder), should be replaced when it is found to be damaged. The O-ring is an easily replaceable part. These O-rings are available from Daisy, and from stores where paintball supplies are sold.



REMOVING THE CO2 SOURCE FROM THE GUN: Whenever the shooter notices that the CO2 pressure is becoming lower in the CO2 bottle (cylinder), it should be removed from the gun. When the CO2 pressure is allowed to become very low, or completely depleted, it may cause a pellet to fail to shoot out of the gun. The pellet may remain inside the chamber or part way down the barrel of the gun. This remaining pellet may, or may not shoot out of the gun when the gun is shot the first time after a full CO2 source has been reinstalled. This can create a very dangerous condition, and can be avoided by not allowing the CO2 source to become completely emptied while the gun is being used. The shooter should always assume that a pellet may be in the gun, and the gun should always be kept pointed in a safe direction, and should NEVER be dry fired unless the gun is pointed in a safe direction.

REMOVING THE 2.5 OUNCE REMOVABLE CO2 BOTTLE (CYLINDER) FROM THE GUN: CO2 pressure can cause the bottle (cylinder) O-ring to seal very tightly in the gun, and can cause the bottle (cylinder) to be harder to unscrew. To help keep this from happening, the shooter should always be sure to oil the O-ring and threads of the bottle (cylinder) before installing it, and should avoid over-tightening it by always using only the wrench provided. While the pressurized bottle (cylinder) is being unscrewed from the gun, a small amount of CO2 can usually be heard escaping. This is normal.



Being sure to keep the gun pointed in a safe direction, and always using only the wrench provided, unscrew the bottle (cylinder) and remove it from the gun.

NOTE: As the bottle (cylinder) is being unscrewed, the shooter should be observant for any movement or loosening of the bottle (cylinder) fittings. If this is found, or if the shooter experiences any problems when they are installing or removing the CO2 source, the gun and CO2 source should be stored in a safe place and the shooter should call the Daisy Customer Service Department for information on handling the problem. Only trained personnel should attempt to work on the refillable bottle (cylinder), or on the gun.



Step 4. LOAD PELLET

With the bolt back, lower the muzzle slightly and load a .177 cal. (4.5 mm) pellet, solid end forward (See Drawing 4A).


Step 5. CLOSE BOLT

Push the bolt handle fully forward. This will chamber a pellet and lock the bolt (See Drawing 4B). The gun will not fire if the bolt is open.

CAUTION: The gun is now loaded and ready to fire. Pulling the trigger now will fire a pellet from the gun. In this condition, it should be handled with extreme care.

Step 6. AIM AT SAFE TARGET

Aim the gun at a safe target. To be a consistent marksman, use the correct sight picture each time you fire your gun (See Drawing 5).



CAUTION: Due to the power of these airguns, use extra caution in selecting a safe target backstop. These models should not be used with BB gun target backstops. Pick targets that cannot be penetrated or that will not cause a ricochet because of their hard surface. Use only targets and traps that are designed for use with high-powered pellet guns. Do not shoot at water.

Step 7. TAKE "OFF" TRIGGER SAFETY

When you are certain the target, backstop and surrounding area are safe, push the trigger safety from the right, fully to the left (RED SHOWING ON LEFT). Your gun is now ready to shoot. In this condition, it should be handled with extreme care.

Step 8. FIRE

After completing the operating steps above, and after making sure the gun is pointed in a safe direction, gently but firmly squeeze the trigger. Repeat steps 1 through 8 to continue shooting.

FAILURE TO SHOOT CO2 If the gun does not shoot CO2, with the safety “ON” (NO RED SHOWING), and with the gun pointed in a safe direction, try retightening the 2.5 ounce bottle (cylinder) with only wrench provided. Do not over tighten.

If the gun still does not shoot CO2, the CO2 source may be empty. The 2.5 ounce refillable bottle (cylinder) can be checked for CO2 pressure by removing it from the gun and pushing inward on the bottle (cylinder) valve pin. If the valve can be opened and no gas escapes, the CO2 bottle (cylinder) is empty, and should be refilled to operate the gun.

FAILURE TO SHOOT A PELLET If the gun does shoot CO2, but does not shoot the pellet, one or more pellets may be jammed in the barrel of the gun. An unfired projectile in the barrel can be a dangerous situation.

 **WARNING:** IF A PELLET DOES NOT FIRE AFTER COMPLETING THE OPERATING STEPS, THE GUN IS JAMMED. KEEP THE GUN POINTED IN A SAFE DIRECTION AND PERFORM THE FOLLOWING STEPS:

1. Put trigger safety “ON” (NO RED SHOWING).
2. Open bolt.
3. Close bolt, and with gun pointed in a safe direction, take the trigger safety “OFF” (RED SHOWING) and fire.

If the pellet still does not fire, follow these steps carefully:

1. Put trigger safety “ON” (NO RED SHOWING).
2. Open bolt.
3. With gun pointed in safe direction, remove CO2 source from the gun using only wrench provided.
4. Invert the gun with the barrel held in the horizontal position.
5. Clear barrel by running a brass or aluminum cleaning rod through from the muzzle end (using a steel rod will damage rifling) and allow the pellet to fall clear of the receiver through the feed track. Be careful not to damage the bolt tip by pushing the rod through too hard. Do not reuse this pellet. Do not allow a pellet to fall into the action of the gun.

NOTE: Should you let a pellet fall into the action of the gun, make every effort to shake it free and get it to fall out. Otherwise, the gun will have to be returned to the Daisy Service Department. (See “Repair of Daisy Guns” section.)

6. Repeat operating Steps 1 through 8. If after following the firing procedure, a pellet is not fired, put safety “ON” (NO RED SHOWING) and return your gun to the Daisy Service Department.

If these steps do not correct the problem, the gun and CO2 source should be stored in a safe place. The Daisy Customer Service Department should be called for information on correcting the problem, or for information on how to return the gun and CO2 source for repair. Do not return the gun to the retailer.

UNLOAD PELLET

The bolt does not extract a pellet. Shoot the pellet at a safe target to unload gun. If a safe target is not available, put trigger safety “ON” (NO RED SHOWING), open bolt, invert the gun with the barrel held horizontal, insert a cleaning rod in the muzzle end and push the pellet out of the barrel. This allows the pellet to fall clear of the action. Do not allow a pellet to fall into the action of the gun. DO NOT use a steel cleaning rod. Use brass or aluminum only.


 **CAUTION:** Never assume the gun is empty of projectiles. Always point the gun in a safe direction.

AMMUNITION

Use only .177 (4.5 mm) lead airgun pellets. Daisy no. 557 match pellets are recommended.

REAR SIGHT INSTALLATION AND ADJUSTMENT

(MODEL 887) This is a universal target sight with a rubber eyepiece, which prevents light reflecting from the sight into your eye.




Installation Step 1. Loosen the bracket mounting screw and plate. Slide the sight onto the dovetail grooves of the receiver. Position the sight forward or to the rear until it suits your eye-sight and/or physique.

Installation Step 2. Tighten mounting screw securely. (See drawing 6)

ELEVATION: To lower the point of impact, turn elevation knob to the left (counterclockwise). To raise the point of impact, turn elevation knob to the right (clockwise), per arrow and word "UP" (See drawing 7)

WINDAGE: To move the point of impact to the left, turn the windage knob counterclockwise. To move the point of impact to the right, turn the windage knob clockwise.

FRONT SIGHT APERTURE INSERTS (MODEL 887)




Your model 887 competition pellet rifle comes with four aperture inserts, 2.6 mm, 3.8 mm, 4.0 mm, 4.4 mm (4.4 mm already in place). To change inserts, follow this procedure:

1. Point the muzzle up and away from you in a safe direction.
2. Open the bolt and put the gun "ON" safety (NO RED SHOWING).
3. Grip the ring at the muzzle end of the sight and turn counterclockwise. If tight, a coin may be used in the slots. (See drawing 8A)
4. Unscrew until aperture is free to be removed by using finger and thumb on side of sight tube, engaging ears on aperture to pull back and upwards. (See drawing 8B)

Note: Apertures have ears of different sizes to ensure the proper positioning when replaced.

5. To install, make sure back locking ring is unscrewed far enough for clearance. Have ears to proper side. Insert in groove and push forward. Tighten locking ring. A coin may be used to assure a firm lock.

REAR SIGHT INSTALLATION AND ADJUSTMENT (MODEL 888)



Installation Step 1. Loosen bracket mounting screws and slide receiver sight onto dovetail grooves of receiver (See Drawing 6A). Position the sight forward or to the rear until it suits your eye-sight and/or physique.

Installation Step 2. Tighten mounting screws securely (See Drawing 6A).

ELEVATION: To lower the point of impact, turn elevation knob to the left (counterclockwise). To raise the point of impact, turn elevation knob to the right (clockwise), per arrow and word “UP” (See Drawing 7A).

WINDAGE: To move the point of impact to the left, turn the windage knob counterclockwise. To move the point of impact to the right, turn the windage knob clockwise, per arrow and letter “R” (See Drawing 7A).

ADJUSTMENT: This precision peep sight is fully adjustable. Each click of the micrometer adjustment results in a .413 minute of angle (.048 inch) shift of pellet impact at 10 meters (33 feet).

FRONT SIGHT APERTURE INSERTS (MODEL 888)




Your model 888 competition pellet rifle comes with additional aperture inserts, one is already in place. To change inserts, follow this procedure.

1. Point the muzzle up and away from you in a safe direction.
2. Open the bolt and put the gun “ON” safety (NO RED SHOWING).
3. Using your index finger (or middle and index fingers if your fingers are slender), push in on the top and bottom of the release plate (See Drawing 8C).
4. With insert release plate pushed in, lift out the aperture insert with thumb and index finger of opposite hand (See Drawing 8D).
5. To replace aperture, depress release plate. Place desired aperture in position with insert tabs in appropriate slots (See Drawing 8D).
6. Front sight apertures provided with this airgun measure: .140 inch, .150 inch, .160 inch and .170 inch. Post front sight width measures 1.7526 mm (.069 inch)

SLING ATTACHMENT

The sling is attached by a detachable sling swivel which connects to a sling bracket on the forward end of the accessory rail. With the sling attached to the swivel and pulled back along the underside of the rifle, the tab end of the sling should be hanging down (See Drawing 9A).



PUTTING SLING ON ARM:


1. Open the arm loop.
2. Turn loop one quarter turn in the direction of the sling arm (i.e., one quarter turn to the left if the sling is going on the left arm) and slip your arm into the loop (See Drawing 9B).
3. Place sling loop on your upper arm either above the bicep near the shoulder or below the bicep.
4. Tighten the sling loop until it is snug enough to remain in place on your arm. It should not be so tight that it restricts the flow of blood to your arm or creates a pulse effect.

LENGTHENING SLING:

Grasp the tab end of the keeper with your trigger hand and lift it up while pulling on the top strand (not the tab end) of the sling (See Drawing 9C).


SHORTENING SLING:

Pull the tab end of the sling away from you until sling reaches the desired length. (See Drawing 9D).



STOCK ADJUSTMENTS


To adjust the stock, loosen screws in butt plate sufficiently to allow insertion of the desired number of spacers (See Drawing 10). Spacers go between stock and butt plate. Each insert will adjust stock length 5/8 inch (.625 inch). After stock adjustment inserts have been added, tighten butt plate screws to lock inserts in place. To shorten the stock reverse this procedure. Be certain spacers are placed so the molded cleats nest in the molded receptacle.



TRIGGER ADJUSTMENT

The trigger in this model is adjustable for travel. This is a Special Purpose Match Precision Gun and is exempt from the 2 lb. (0.9 kg) minimum trigger pull standard.

The trigger adjustment screw is located behind the trigger guard (See Drawing 11). The adjustment screw can be turned outward until it has no effect and trigger travel is at the maximum, or it can be turned inward to shorten the trigger travel. To adjust the trigger travel in this model, the gun should be kept pointed in a safe direction, the safety should be at “ON” (NO RED SHOWING), the gun should be unloaded, and the CO₂ source should be removed from the gun.



CAUTION: The trigger should be adjusted by an experienced shooter only.

After the trigger has been adjusted, the gun should be treated with caution. Coaches and instructors should make sure that inexperienced shooters use this model with the trigger adjustment screw backed out to maximum trigger travel.

For target shooting, experienced shooters may find that the best trigger travel setting can be obtained by [with the safety at “ON” (NO RED SHOWING), the gun unloaded, and with the CO₂ source removed] carefully turning the adjustment screw inward until slight resistance is felt.

After the trigger has been adjusted, (with the gun pointed in a safe direction, and with no pellet or CO₂ in the gun) it should be dry fired several times, and the safety tried several times to make sure that the trigger, sear, and safety are all functioning correctly. If the gun does not seem to be functioning correctly, the adjustment screw should be turned outward 1/2 turn, and the gun tried for function again.

As the trigger is being adjusted, the shooter should be careful that the adjustment screw is not forced, because the sear and the safety mechanism can be damaged.

If the shooter has questions about the proper way to adjust the trigger, they can call the Daisy Customer Service Department for information on doing this.

BURST DISK SAFETY PRESSURE RELIEF

The 2.5 ounce refillable CO₂ bottle (cylinder) has a burst disk safety pressure relief on the front fitting of the bottle (cylinder). The disk will burst, or rupture to safely relieve excess CO₂ gas pressure, to prevent the pressure from becoming too high.

The pressure inside the bottle (cylinder) could become too high from the bottle (cylinder) being overfilled with CO₂, or from the bottle (cylinder) becoming heated by being left in direct sunlight or from some other source.

The burst disk is a replaceable part, but replacing the disk should be done by trained personnel only. Ruptured burst disks can be replaced by personnel at stores where these CO₂ bottle (cylinders) are filled.

When a burst disk does rupture to relieve the excess pressure in the CO₂ bottle (cylinder), all of the CO₂ in the bottle (cylinder) will escape rapidly from the bottle (cylinder). The rapidly emptying CO₂ bottle (cylinder) will quickly become coated with frost. The shooter should avoid contact with the escaping CO₂ and the frosted bottle (cylinder). If the disk bursts inside an automobile, or in some other enclosed area, a window or door should be opened to allow the CO₂ to dissipate.

PROPER CARE

With periodic cleaning and lubrication, your 887/888 will provide many years of shooting enjoyment. As is the case with conventional firearms, abuse, neglect and continued exposure to the elements will impair the performance of any airgun and could make the gun unsafe. Learn to take care of your 887/888 and it will serve you well.

 **CAUTION:** Never attempt to clean this gun until you put the trigger safety in the “ON” position (NO RED SHOWING), have made absolutely certain that the gun is not loaded, have the bolt in the fully open position, and have the CO2 source removed from the gun.

STOCK AND FOREARM: The wooden stock may be wiped clean with a damp rag, and lightly waxed.

EXTERIOR PARTS: Exposed metal parts (i.e., receiver, barrel, etc.) should occasionally be wiped clean using a soft, lightly oiled cloth. Use a clean 30-weight non-detergent motor oil.

BARREL: The barrel should be cleaned occasionally to maintain accuracy. We recommend using Daisy Model 5878 Cleaning Kit. To clean barrel, open bolt, remove CO2 source, then insert a brass or aluminum cleaning rod and oil saturated patches into the muzzle end of the bore. Retract the rod and patch from the barrel. Repeat this procedure several times with oiled patches, then switch to dry patches. Continue using dry patches until most of the oil is removed from the bore.

NOTE: Be careful not to damage the sealing tip on the bolt when the rod tip enters the loading area. It may be necessary to clean the barrel approximately every 50 shots to maintain maximum accuracy. Frequent cleaning may be necessary when the gun is new, and until excess oil is removed.

LUBRICATION

The easiest and best way to lubricate these models is to place a drop of 30-weight non-detergent motor oil on the CO2 source before it is installed into the gun. Using the 2.5 ounce refillable CO2 bottle (cylinder), the gun can be lubricated each time it is installed into the gun. This can be done by placing one drop of 30-weight non-detergent motor oil onto the center of the face of the fitting that screws into the gun. This will be on the valve pin on the 2.5 ounce refillable CO2 bottle (cylinder). Use one drop only. More than that can cause the bottle (cylinder) or adapter to seem to be completely screwed into place when it is not. CO2 will not feed into the gun until the bottle (cylinder) has been retightened. Also, too much oil can flood the valve of the gun and cause the gun to shoot low pellet velocities. ONE DROP OF OIL WILL LUBRICATE THE GUN PROPERLY.

IMPORTANT: The only oils recommended for use in the 887/888 are 30-weight, automotive motor oils. DO NOT use light, household type oils or aerosol type spray lubricants since they may contain substances or additives harmful to the rubber seals and other components.

STORAGE

To make your 887/888 safe for storage or transporting, proceed through operating Steps 1 through 8, omitting Step 4 (Loading), WHILE POINTING THE GUN IN A SAFE DIRECTION FOR THE ENTIRE TIME. Then put the trigger safety “ON” (NO RED SHOWING). This will ensure that the hammer is fired, that there is not a pellet in the chamber and that the trigger safety is “ON.” Remove CO2 source.

NEVER STORE A LOADED OR COCKED GUN. KEEP AWAY FROM CHILDREN AND UNTRAINED SHOOTERS. Always store pellets in a place separate from the gun to keep them from untrained shooters. Before putting your gun away, make sure it is clean, dry, oiled, unloaded, uncocked and that the CO2 cylinder has been removed. If the gun is to be stored for a long period of time, a light coat of oil in the barrel will help prevent corrosion.

MODIFICATION

 **CAUTION:** The components of this gun were engineered to deliver optimum performance. Any modification or tampering with a gun may cause a malfunction and may make it unsafe to use. Any change in performance, such as a lowered trigger force and shortened trigger travel, indicates possible wear. Such guns should be inspected, replaced, or properly repaired by qualified personnel. Any gun that has been dropped should be checked by qualified personnel to insure that its function has not been affected.

 **WARNING:** A GUN THAT IS NOT OPERATING PROPERLY MAY BE DANGEROUS. IT SHOULD BE KEPT SAFELY FROM USE BY ANYONE UNTIL REPAIRED OR DESTROYED. DO NOT TRY TO TAKE THE GUN APART. IT IS DIFFICULT TO REASSEMBLE, AND IMPROPER REASSEMBLY CAN CAUSE A HAZARDOUS CONDITION.

GUNS IN WARRANTY

LIMITED ONE-YEAR WARRANTY

For one year from date of purchase, Daisy will repair or replace and return this gun, free of charge, if defective in material or workmanship. Service is available by returning the gun to Daisy Outdoor Products (refer to important note below). Attach to the gun, your name, street address, telephone number, description of problem and proof of date of purchase (sales slip). Package and send, transportation prepaid, to Daisy. This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state.

IMPORTANT: You can return your inoperative rifle to Daisy for repair via United Parcel Service (UPS). Be sure to put “ON” (NO RED SHOWING) safety and unload all ammo before returning the gun to Daisy. You must include your street address for Daisy to send your rifle directly back to you through UPS delivery.

GUNS OUT OF WARRANTY

If your Avanti gun needs repair, please call 1-800-713-2479 for repair charges. Daisy will repair the gun or replace it with a reconditioned gun of the same model, if available; otherwise, with a model of equivalent quality.

Daisy Outdoor Products
Service Department
308 W. Stribling Drive
Rogers, AR 72756 U.S.A.


NOTE: AVANTI air guns do not come under the provisions of the “Gun Control Act Of 1968” and can be shipped via UPS (not mailed).

MODEL 887/888 SPECIFICATIONS

| | |
|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------|
| ACTION | CO2 power, single shot bolt |
| CALIBER | .177 cal. (4.5 mm) |
| AMMUNITION | .177 cal. (4.5 mm) lead air gun pellets |
| FRONT SIGHT | 887 - Globe type with changeable aperture inserts; 888 - Hooded with changeable aperture inserts. |
| REAR SIGHT | 887 - Dilofter sight with micrometer click adjustment for windage and elevation; 888 - Micrometer adjustable peep sight |
| BARREL | Rifled steel with barrel weight, 12 lands and grooves, right-hand twist, precision bore sized for match pellets |
| MUZZLE VELOCITY | 500 fps (152 mps) |
| MUZZLE ENERGY | 4.28 ft. lb. (5.8 J) |
| TARGET DISTANCE | 33 ft. (10 m) |
| MAXIMUM SHOOTING DISTANCE* | 257 yds. (235 m) |
| LENGTH | 38.5 in. (97.7 cm) |
| WEIGHT | 887 - 7.3 lbs.; 888 - 6.9 lbs. |
| ADD ON ACCESSORIES | Standard dovetail mount in receiver to accept a scope; nylon web sling |

*With muzzle pointed upward at optimum angle

AVANTI Models 887 and 888 Parts List



| Key | Part No. | Description |
|-----|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | 888-1 | 888 stock, butt plate and screws |
| 1A | 887-1 | 887 stock, butt plate and screws |
| 2 | 888-2 | Stock spacers (3 each) |
| 3 | 888-3 | Trigger housing |
| 4 | 888-4 | Safety assembly (includes ball & spring) |
| 5 | 888-5 | Trigger assembly |
| 6 | 888-6 | Hammer and spring |
| 7 | 888-7 | Receiver |
| 8 | 888-8 | Bolt handle assembly (includes bolt, bolt handle and spring) |
| 9 | 888-9 | Valve body and barrel assembly |
| 10 | 888-10 | Right filler |
| 11 | 888-11 | Left filler |
| 12 | 888-12 | Frame |
| 13 | 888-13 | Barrel band |
| 14 | 888-14 | 888 front sight and set screws |
| 14A | 887-14 | 887 front sight and set screws |
| 15 | 888-15 | 888 sight inserts |
| 15A | 887-15 | 887 sight inserts |
| 16 | 888-16 | O-ring |
| 17 | 888-17 | Burst disk and relief valve |
| 18 | 888-18 | Screw assortment (includes 2 receiver screws, 1 trigger housing screw, 1 trigger adjustment screw, 1 rear tie down valve body screw, 2 stock screws, 1 seat screw) |
| 19 | 888-19 | O-ring valve group (includes O-ring, spring, valve) |
| 20 | 888-20 | Adapter |
| 21 | 888-21 | 888 rear sight |
| 21A | 887-21 | 887 rear sight |

